

1. Room Temperature Measurement

Objective: Measure room temperature using a TMP36 sensor and display it on the serial console.

Steps:

1. **Place Components:** Add an Arduino, TMP36 sensor, and connect the components in Tinkercad.
 2. **Connect Sensor Power:** Attach the TMP36 sensor's VCC pin to the Arduino's 5V pin and GND to GND.
 3. **Connect Analog Pin:** Connect the TMP36's output pin to the Arduino's analog input A0.
 4. **Initialize Serial Monitor:** In the code, add `Serial.begin(9600);` in the `setup()` function to initialize serial communication.
 5. **Read Sensor Value:** In the `loop()` function, use `analogRead(A0)` to read the TMP36 sensor value.
 6. **Convert to Celsius:** Convert the analog reading to temperature in Celsius using `tempC = (voltage - 0.5) * 100;`.
 7. **Display on Serial Console:** Print the temperature to the serial monitor with `Serial.println(tempC);`.
 8. **Add Delay:** Add a delay of 1 second using `delay(1000);` for continuous readings.
 9. **Run Simulation:** Start the simulation in Tinkercad and open the serial monitor to view the temperature readings.
 10. **Observe Output:** Verify that the temperature data updates every second.
-

2. Gas Detection

Objective: Detect the presence of gas (like smoke) using an MQ sensor and display the status on the serial console.

Steps:

1. **Place Components:** Add an Arduino, MQ2 gas sensor, and LED to the workspace.
2. **Connect Power:** Connect the MQ2 sensor's VCC to 5V and GND to GND on the Arduino.
3. **Connect Analog Pin:** Connect the MQ2 sensor's analog output pin to the Arduino's A0.
4. **Initialize Serial Monitor:** Use `Serial.begin(9600);` in the `setup()` function.
5. **Read Sensor Value:** In the `loop()` function, use `analogRead(A0)` to read the sensor value.
6. **Set Threshold:** Define a gas threshold value (e.g., 300) to detect gas presence.
7. **Check Gas Levels:** Use an `if` condition to compare the sensor value with the threshold.

8. **Display Result:** If gas is detected, print "Gas Detected! " ; otherwise, print "No Gas" to the serial monitor.
 9. **Add Delay:** Include `delay(1000);` to update every second.
 10. **Run and Observe:** Start the simulation and monitor the serial console to see gas detection status.
-

3. Obstacle Detection with Infrared Sensors

Objective: Detect obstacles using an IR sensor and display the approximate distance on the serial console.

Steps:

1. **Place Components:** Add an Arduino and an IR sensor to Tinkercad.
 2. **Connect Power:** Attach the IR sensor's VCC to 5V and GND to GND on the Arduino.
 3. **Connect Digital Pin:** Connect the IR sensor's output pin to Arduino's digital pin, e.g., D2 .
 4. **Initialize Serial Monitor:** In `setup()` , add `Serial.begin(9600);` .
 5. **Read IR Sensor State:** In the `loop()` , use `digitalRead(D2)` to check if an obstacle is detected.
 6. **Define Threshold:** Determine a threshold for distance (e.g., if signal is HIGH, obstacle is close).
 7. **Display Detection Status:** Use `Serial.println("Obstacle Detected")` if an obstacle is detected.
 8. **No Obstacle Condition:** Print "No Obstacle" if no obstacle is detected.
 9. **Add Delay:** Use `delay(500);` to check every half second.
 10. **Run Simulation:** Start simulation and view the serial monitor for obstacle detection feedback.
-

Using an **ultrasonic distance sensor** for the fourth experiment in Tinkercad allows you to measure the distance of an object more accurately than using a potentiometer. Here's a revised 10-step procedure to implement this experiment with an ultrasonic sensor, such as the **HC-SR04**.

4. Distance Measurement with Ultrasonic Sensor

Objective: Measure the distance of an object using an ultrasonic sensor and display the result on the serial console to simulate speed or distance changes.

Steps:

1. **Place Components:** Add an Arduino and an HC-SR04 ultrasonic sensor in Tinkercad.
 2. **Connect Sensor Power:** Connect the **VCC** pin of the ultrasonic sensor to the Arduino's 5V and **GND** to GND .
 3. **Connect Trigger and Echo Pins:**
 - Connect the **Trig** pin of the sensor to a digital pin on the Arduino, e.g., D9 .
 - Connect the **Echo** pin to another digital pin, e.g., D10 .
 4. **Initialize Serial Monitor:** In the `setup()` function, add `Serial.begin(9600);` to enable serial communication.
 5. **Configure Sensor Pins:** In `setup()` , set the **Trig** pin as `OUTPUT` and the **Echo** pin as `INPUT` :
 6. **Send Trigger Pulse:** In `loop()` , send a 10-microsecond pulse to the Trig pin to start the measurement:
 7. **Read Echo Pulse:** Use `pulseIn(10, HIGH);` to measure the duration it takes for the sound wave to return after hitting an object:
 8. **Calculate Distance:** Convert the pulse duration to a distance in centimeters:
 9. **Display Distance:** Print the distance to the serial monitor with `Serial.println(distance);` .
 - You can use this as an approximation of “speed” by noting how distance changes over time.
 10. **Add Delay:** Use `delay(500);` to update every half second and repeat the measurement process.
-

5. Smart Home System using Wifi Module

Procedure

1. **Prepare Components:** In Tinkercad, add an Arduino and an LED. Connect the LED's positive (anode) leg to a digital pin, such as pin 13, and the negative (cathode) leg to the ground (GND) via a resistor.

2. **Define the LED Pin:** In the Arduino sketch, specify the digital pin (e.g., pin 13) where the LED is connected. Set this pin as the LED control pin.
 3. **Set Up Serial Communication:** In the `setup()` function, initialize serial communication with the `Serial.begin(9600);` command. This allows the Arduino to receive commands from the serial monitor.
 4. **Configure LED Pin as Output:** Also in the `setup()` function, set the LED pin as an output using `pinMode()`. This enables the Arduino to control the LED's state (on or off).
 5. **Check for Serial Input:** In the `loop()` function, use `Serial.available()` to check if any data has been entered in the serial monitor. This tells the Arduino to listen for commands.
 6. **Read the Command:** When a command is detected, use `Serial.readString()` to read the input from the serial monitor. This command reads all characters entered until a newline is detected.
 7. **Interpret Command to Turn LED On:** If the received command is "s", turn on the LED by setting the LED pin to HIGH. This simulates turning on a light based on a user instruction.
 8. **Interpret Command to Turn LED Off:** If the command received is "e", turn off the LED by setting the LED pin to LOW. This simulates turning off the light on user command.
 9. **Test the Setup:** Start the simulation and open the serial monitor. Type "s" to turn the LED on, and type "e" to turn it off, then press Enter.
 10. **Observe the LED Behavior:** Verify that the LED responds accurately to each command. Use different commands to ensure the LED only responds to "s" (on) and "e" (off).
-

6. PubNub Dashboard for Student Details

Objective: Send student data (name, age, grade) to a PubNub server and retrieve it back for display on a common dashboard.

Procedure

1. **Create a PubNub Account:** Go to [PubNub's website](#) and sign up or log in to your account. Once logged in, create a new PubNub app for this project.
 2. **Obtain PubNub Keys:** In the app dashboard, find and copy your **Publish Key** and **Subscribe Key**. These will be needed for your HTML code to send and retrieve data.
 3. **Setup HTML Page:** Create a simple HTML file named `dashboard.html`. Add input fields for **Name**, **Age**, and **Grade**, and a button to submit data.
 4. **Include PubNub JavaScript SDK:** Add a `<script>` tag to include the PubNub SDK in your HTML. This allows your webpage to interact with the PubNub server.
 5. **Initialize PubNub in JavaScript:** In your HTML file, add a `<script>` section to initialize PubNub with your publish and subscribe keys.
 6. **Send Data to PubNub:**
 - Add an event listener to your "Submit" button. When clicked, it captures the name, age, and grade input values.
 - Publish this data to a PubNub channel (e.g., `"student_channel"`).
 7. **Subscribe to the PubNub Channel:**
 - Use PubNub's `subscribe` function to listen for new messages on the `"student_channel"`.
 - Every time data is published to this channel, it will be received and displayed on the HTML page.
 8. **Display Received Data:**
 - When a message is received, update a section of the HTML page (e.g., a `<div>` or `<table>`) to show the latest student details.
 9. **Test the Setup:** Open the `dashboard.html` file in a browser. Enter sample data (e.g., "Alice, 12, 7th Grade") and submit. The data should appear immediately in the display section of the dashboard.
 10. **Observe Real-Time Updates:** Add more entries or open multiple instances of `dashboard.html` in different browser tabs. All connected clients should see new student data in real time.
-